How to Update SSD Firmware

2021 | 10 | 26

How to update SSD firmware

Execute ADATA SSD ToolBox. Select the updated SSD.

How to update SSD firmware

Click "Utility" page, and click Firmware Update / "CHECK UPDATE".

How to update SSD firmware

When window pop up, please click "OK".

How to update SSD firmware

Select the save path and click "Save".

How to update SSD firmware

Extract firmware updater and follow user guide to update firmware.

TROUBLESHOOTING

Condition 1 : Connection to server failed

Please confirm your internet connection first.

You already have the latest firmware version, no need to update.

XTREME PERFORMANCE GEAR